



TITLE:

What is the initial timer period about EM57000 series

REVISED DATE	:	14, JUNE, 1998
REVISED VERSION	:	1.0
APPLY TO CHIPS	:	EM57000 Series Chip
APPLY TO SOFTWARE	:	ALL EM57000 series coding system above version 2.1

SEE ALSO:

1. The timer in EM57000 series can be adjusted whenever it is required.
The available timer period is :
1 mS, 8 ms, 32 ms and 64 mS.
2. The initial timer period will be set as 8 ms when power on.
3. To change timer period by program, use following commands :

```
MOV TIMER #TDATA
```

TDATA can be 0 to 3 as following shown :

```
MOV TIMER #0      ; Set as 1 ms as timer period  
MOV TIMER #1      ; Set as 8 ms as timer period  
MOV TIMER #2      ; Set as 32 ms as timer period  
MOV TIMER #3      ; Set as 64 ms as timer period
```